

Time Clock Instructions

WHERE TO START:

- 1) Turn on the unit – switch is on the right side
- 2) Start where turned off last? **“NO”**
- 3) Model Code **“871”**
- 4) Work Wirelessly? **“YES”**
- 5) Select a group
 - a. Press “NO” until the correct rink is displayed.
 1. A Rink is **RINK #1, Board #1** (do not mistake Rink for Court)
 2. B Rink is **RINK #2, Board #2** (do not mistake Rink for Court)
- 6) Penalty Time Out? **“NO”**
- 7) Hit **“SET”**, then **“TIME”**
- 8) Enter **“3:00”** (or amount of time for warm up or per period based on age level)
- 9) Hit **“YES”** if correct. Hit **“NO”** if you need to re-enter the time
- 10) Periods? **“1”** (this changes per period)
- 11) Be sure that scores are set to 0 for the 1st period
- 12) Use the rocker switch on the hand held to start and stop the clock at whistle.

SCORING:

- 1.) Push **“HOME SCORE”** or **“GUEST SCORE”**
- 2.) Push **“1”** (Push “1” each time score increases and it adds 1 to the current score)

PENALTY:

- 1.) Push **“SET”**
- 2.) Push **“HOME PENALTY”** or **“GUEST PENALTY”**
- 3.) Type **“1:30”** (or however long penalty is for age)
- 4.) Push **“YES”**
- 5.) Type in Players Jersey Number **“##”** (NOTE: Player 5 would be 05)

CLEAR PENALTY:

- 1.) Push **“HOME PENALTY”** or **“GUEST PENALTY”**
- 2.) Push **“PENALTY CLEAR”**
- 3.) Push **“YES”**