Clock Instructions

SCAN FOR EARLY STATE OF THE BIRD OF THE BIRD SOON SERIES CONTROL CONSCIL

To start - turn on the clock ON/OFF button is on the back.

Screen will read: 4402 Resume Game?

Press: Enter * Yes
OR Return to Game

Press: Menu then

Press Enter * Yes

Until your screen looks like

SCAN FOR BROWN
OFERANCE
A SUPPORT
MINIME B: 80, 8 + 45

MINIME B: 8 : 45

MINIME DIA TO THE BOOK SERIES
CONTROL CONSOLE

ALL SPORT
5000 SERIES
CONTROL CONSOLE

TIME B: 80, 8 + 45

MINIME DIA TO THE BOOK SERIES
CONTROL CONSOLE

TO THE BOOK SERIES
CONTROL CONSOLE

TO THE BOOK SERIES
CONTROL CONSOLE

THE BOOK SERIES
CONTROL CONTROL CONSOLE

THE BOOK SERIES
CONTROL CONTROL CONTROL CONTROL CONTROL CONTROL CONTROL

THE BOOK SERIES

Set Clock for Warm Up: Push: Set Main Clock 5:00.0


Press: Enter *Yes

Repeat this step for Period 1 (15:00.0 or


12:00.0)

At the end of the Period Press Period +





Remember to record Shots on Goal (Home & Guest) For Goals Press: Score +1 Goals ARE also SOG +1



To <u>ENTER</u> a penalty: Enter under Home or Guest side

Push: Player #

Push: Enter*Yes
Enter Penalty length (2:00 is default)

Push: Enter*Yes

Remember - COINCIDENTAL PENALTIES ARE NOT PUT ON THE BOARD

HOCKEY/LACROSSE/
HANDBALL

CODE TYPE
4000 S0G CONSOLE
4401 W/O SOG
402 W SOG
403 W SOG
404 W SOG
405 W SOG
405 W SOG
405 W SOG
406 W SOG
407 W SOG
407 W SOG
408 W SOG
409 W SOG
400 W SOG


To <u>CLEAR</u> a penalty when goal is scored: Enter under Home or Guest side Push: Delete Penalty

Enter: Score +1

Penalties will clear automatically when time expires



Clock Instructions



To Clear a Penalty when


MULTIPLE PENALTIES ARE ON THE BOARD

You will be asked which penalty to clear.

#1 is top penalty. If you need to clear a

different penalty use the arrows to select the

correct penalty and then press Enter * Yes



To set a penalty during a <u>run time period</u>

Press: Disable Penalty Clock

Push: Player Penalty

Enter length of penalty

Press Enter * Yes

When puck drops

Press: Enable Penalty Clock



When a <u>penalty carries over between periods</u>
At end of period


Press: Disable Penalty Clock

Then set main clock for 1:00.0 (time between periods). At end of intermission:

Press: Period+

And set main clock for next period (15:00.0 or 12:00.0)

Then Press: Enable Penalty Clock



To Enter a <u>Time Out</u>

Press: Time Out On/Off

This will automatically bring up a 1:00 TO

Press Enter * Yes



To Enter a <u>Time Out</u>
with a Penalty on the Board
Press: Disable Penalty Clock

Press: Time Out On/Off

This will automatically bring up a 1:00 TO

Press Enter * Yes
When penalty is over
Press: Enable Penalty Clock

GAME OVER!

At the end of the game to clear the clock:

Press Menu, then down arrow 5x until Display Menu?

Press: Enter * Yes

Press down arrow 3x until Select ToD? Press: Enter * Yes 2x (for 12 HR display)

Adjust time using keypad Press: Enter * Yes Press 2: select ToD

Press: Enter * Yes to erase game data

Thank you!

