

# NEVCO SCORE BOX INSTRUCTIONS

## Getting Started

First, if the machine is not on, turn it on by flipping the switch on the bottom right side of the score box.

If the machine was off it will ask you if you want to start where you turned off last. It will give you the option of “**YES**” or “**NO**”. You want to choose “**YES**”.

## Resetting the Clock

Hit **SET**...then **TIME**... and set to the period length. Make sure to enter a colon when setting the time. After entering the time hit “**YES**” to complete.

i.e. **SET...TIME...14:00...YES**

Now the machine will ask you for a period. Enter **0**, **1**, **2**, or **3** and the box is ready to go.

## Scoring

Reset both Teams Scores to “**0**”.

Do this by hitting **SET...HOME SCORE** or **GUEST SCORE** and then “**0**”.

To display a goal scored on the scoreboards hit either **HOME** or **GUEST SCORE** and then the “**1**”. The score box will automatically add a goal, so always hit “**1**”.

## Setting Penalties

To set a penalty you must first hit **SET... HOME** or **GUEST PENALTY**. Enter the duration of the penalty i.e. **2:00** then hit **YES**. The machines will now ask you for the player’s #. Enter this by using the number pad, but keep in mind it must be a 2 digit number. If the player is number “**8**” it must be entered as “**08**”.